


Index No	Part No	Description	Qty.	Index No	Part No	Description	Qty.
1	8940200742	Cross Bit	1	35	8940200221	Ball	1
2	8940200751	Wire Collar	1	36	8940200145	O-ring	1
3	8940200752	Spring Seat	1	37	8940200183	Reverse Sleeve	1
4	8940200753	Spring	1	38	8940200179	Pin switch	1
5	8940200754	Lock Sleeve	1	39	8940200182	Reverse Axle	1
6	8940208129	Clutch housing	1	40	8940200809	Steel Ball	1
7	8940200757	Bushing	1	41	8940200181	spring	1
8	8940200257	Adjusting Gasket	1	42	8940202448	Screw	1
9	<u>8940200809</u>	Steel Ball	1	43	8940200180	Reverse Valve	1
10	8940200909	Anvil Shaft	1	44	8940201329	spring pin	1
11	8940200258	Bushing	1	45	8940200178	Trigger / Button	1
12	8940200259	Cage	1	46	8940200215	pin	1
13	8940200261	Pin	2	47	8940200219	pin	1
14	8940200260	Impact hammer	2	48	8940200177	Rubber Sleeve	1
15	8940200262	Transmission Sleeve	1	49	<u>8940202447</u>	O-ring	1
16	8940200254	Snap Ring	1	50	8940200173	Muffling Hood	1
17	8940200265	Pressing Thread Bush	1	51	8940200175	Outer Silence Hood	1
18	<u>8940201057</u>	Bearing	1	52	8940200174	Inner Silence Hood	1
19	8940200800	Front Plate-end	1	53	8940200799	Silencer Felt	1
20	8940202385	Spring Pin	1	54	8940200176	gasket	1
21	8940200841	rotor	1	55	8940200269	Hole Spring Collar	1
22	<u>8940200774</u>	blade	10	56	8940200808	Air Inlet	1
23	8940200161	spring pin	2	57	8940200353	cap plug	1
24	8940200801	cylinder	1		8940208074	CP ring (not shown)	1
25	8940200802	rear plate	1		8940204098	Warning Label (not shown)	1
26	<u>8940202422</u>	Bearing	1		6158729000	Name Plate (not shown)	1
27	<u>8940200167</u>	Paper Gasket	1		8940208402	Tune-up kit (Incl. 9, 18, 22, 26, 27, 28, 31, 36, 49)	
28	<u>8940200166</u>	O-ring	2				
29	8940208130	Handle	1				
30	8940202285	suspensor	1				
31	<u>8940202378</u>	O-ring	1				
32	8940200220	Hole Spring Collar	1				
33	8940200185	spring	1				
34	8940200184	Valve Seat	1				
					2050503283	OPERATOR'S MANUAL	
					8940168583	CE DECLARATION	
					6159948710	SAFETY INSTRUCTIONS	

Recommended accessories